



8' ground rod, clamp and #6 bare copper ground wire  
 (Supplied and installed by consumer)  
 Grounding conductor shall be connected from the ground  
 lug in meter base to the ground rod(s)  
 Cooperative requires the meter base to be grounded

When the temporary service is not part of the permanent service the consumer must provide all materials on the service pole, including the meter base and the cable to be connected to CVEC's pole. CVEC will provide meter.

**TEMPORARY OVERHEAD SERVICE**



**CENTRAL VIRGINIA  
 ELECTRIC COOPERATIVE**

**11/07/2012**